

Processing & Installation Sheet

Pureflex board

MATERIAL PREPARATION

Storage	Store in a dry place protected from UV radiation. Temperature range: -10 °C to +40 °C.
Transport	Handle with care, avoid mechanical damage.
Preparatory steps	Remove packaging, check panels for damage.

CUTTING & PROCESSING

Recommended tools	Cutter, carpet knife, possibly a thermal cutting device.
Notes	Use a flat support surface for precise cutting, ensure clean cut edges.

INSTALLATION & ASSEMBLY

Fixing methods	Mechanical fixing or bonding, depending on the application. The material is hydrophobic, so bonding with water-based adhesives is not ideal.
Installation notes	Ensure clean and precise installation, seal joints properly.

CLEANING & MAINTENANCE

Site / Tools	Use an industrial vacuum cleaner to remove dust, clean surfaces with soapy water.
Material	No special maintenance required. Protect against heavy mechanical stress.

DISPOSAL & RECYCLING

Thermal disposal	Possible
Material recovery	Possible due to high ageing resistance, if not combined with other materials.

SAFETY INSTRUCTIONS

PPE	Gloves, safety goggles, dust mask.
Specific hazards	Dust may form during cutting, which can irritate the respiratory tract.
Legal regulations	Dispose of according to local regulations.